Shaw High Definition TV – Quick Reference Guide

DEMAND

СН

→I

+

The Shaw HDPVR Remote

HD Programming Guide

Watch Cable •

Set to turn on/off all your devices at once

Input

Cycle through video inputs on TV

Quick Menu

Press A to access key features quickly

On Demand

Access Shaw On Demand movies and TV shows

Guide

Displays the programming guide. Click more than once to cycle through alternate views

Arrows

Move highlighted section while in the guide or Shaw On Demand. Press the **UP** arrow to display the Quick Bar and Favourites Bar while watching TV

Info

Displays information for currently selected program

Swap

Swap PVR tuners

Setup

Hold for three seconds to begin the setup process

Cable

If the Shaw HDPVR is not responding, try pressing this key first

Menu

Displays Main Menu

Day +/-

Move a day back or forward in the programming guide

Page up/down

Navigate the programming guide and Shaw On Demand menus

List

See what's recorded on your PVR

Record

Set recordings

Video playback controls

Control playback of PVR and Shaw On Demand content

Fav

Add channels or programs to your Favourites List while in the guide. In Shaw On Demand, press to add a title to your Wishlist

How to program your Shaw Remote

- Step by step instructions are located on the back of the remote
- Or visit
 urcsupport.com/shaw

For more information

• Shaw Remotes: Press the MENU button, select "Help" and select "Shaw Remotes"

Shaw)

HD Guide Tips & How-to Videos: Press the MENU button, select "Settings" or "Help".
 Or visit shaw.ca/hdguide

The on-screen programming guide is your source for finding out what to watch. Press **GUIDE** on your remote to access up to 2 weeks worth of TV Listings and TV on demand. The first press brings you to the Full Screen Guide, second press is the Traditional Guide and the third press brings up the Mini Guide.

No need to search for the HD Channel anymore

HD Grouping: You can adjust your setting so that all HD channels are grouped together at the beginning of the channel listings.

Auto HD:

The days of searching your Guide for the HD version of a channel are over. Now, when you are subscribed



to both the SD and HD version of a network, you will automatically receive the high-definition feed on the lower channel number. This ensures you always receive the best picture quality available. Simply look for the HD icon next to the channel number.

Quick menu

Simply press the A button on your remote once and the Quick Menu will appear over any video or guide screens. It's designed to allow you to quickly access applicable guide features.

The Quick Menu changes and customizes your options depending on what you're currently doing.

Using your PVR

Press the **O Record** button on your remote at any time while in the guide to record the highlighted program. You will be prompted to record a single episode or to set up a series recording.

Setting up a Series Recording is easy. Simply follow the on-screen prompts. You can change your Series Recordings settings at any time. Press the **MENU** button on your remote, select "Recordings" and select "Series" from the tabs displayed.

You can also select "Recordings" from the Main Menu to access your Recordings, Schedule, PVR Settings and more.





Favourites

The Favourites feature on this guide goes way beyond your favourite channels – it's the content you want to watch now.

- · Use pre-set themes like "Movies," "HD," "Sports" or create up to five customized Favourites lists, including your favourite show(s), genre, channel(s) or specific category
- Access Favourites by pressing the MENU button on your Shaw Remote and then select from any of the pre-set or customized Favourites icons displayed
- To create a new Favourites list or edit an existing list, press the A button to access the Quick Menu and select **FAVOURITES**
- · You can also add a specific program or channel to your Favourites list while in the guide by pressing the **FAV** button

Shaw On Demand



The ultimate viewing experience.

- · Access over 10,000 titles and 1,700 movies in HD with Shaw On Demand. Catch up on your favourite primetime shows for FREE, 24 hours after they air
- · To get started, press the **ON DEMAND** button on your Shaw Remote
- · With VOD Quick Launch, you can easily access Shaw On Demand right from the guide on select channels. Simply arrow **LEFT** to the **②** icon and instantly access on demand content from that channel

Search

- · Search for a specific program by actor, title or description
- · From the Main Menu, select **SEARCH**
- · Using the arrow buttons, highlight the letters on the key pad and push **OK** to have them appear in the search field
- Press the **RIGHT** arrow to advance to the results column. You can choose to view "TV Programs" or "On Demand" results
- · Highlight the program you want to watch and press **OK**

Main Menu

For easy access to all of your HD Guide features, simply press **MENU** on your remote, then select from the options available, including Shaw On Demand, Events, Favourites, Settings and more. You can even order movies and TV content from Shaw On Demand right from the Main Menu.



These icons will appear in the Main Menu. Highlight and select an icon with your remote and you will immediately access the area indicated.



Events: Enjoy instant access to all of our Pay Per View events.



Shaw On Demand: Catch up on your programs or watch a flick.



Recordings: Directly access your recordings, scheduled recordings, series management. PVR Settings and more.



Search: Easily look for a specific program by actor, title or description.



Watch TV: Select this to view the channel you were last tuned to.



Guide: Easy access to the on-screen programming guide.



Favourites: Select this icon to create a new customized Favourites list. New and previously created customized Favourites lists and eight pre-set lists (HD, Kids, Movies, Sports, Reality, Drama, Comedy, News) are also located on the same row.



Help: The help feature will provide you with all of the solutions you're seeking including various "How-to" videos.



Settings: View and customize your current settings or watch a variety of "How-to" videos to get you started.



My Orders: Quick access to your recently ordered Shaw On Demand content.



Wishlist: Easily access your current Shaw On Demand Wishlist.